

INSTRUCTIONS

LB135 / LBB135 Walking Poles



To extend the pole, fully open the lever lock.



Grasp the section immediately below the lever and slide it out to the desired length. Use the markings on this section (metric & imperial) as a guide. Then fully close the lever lock.



Grasp the pole end around the basket and slide it out fully until the twin button lock engages.

For LBB135: ensure both sets of twin button locks engage.



To collapse the pole, fully open the lever lock. Then slide all sections back into the handle in one movement. Close the lever lock.



Lever tension can be adjusted via the two screws. If pole slips under load, tighten screws 1/4 of a turn. Repeat until pole holds under load. Do not tighten beyond this point. **Do not over-tighten** or you will damage the lock.

Care & Maintenance

If poles get wet or dirty during use, rinse in fresh water and leave fully extended (at maximum length) to dry. Wipe down with soft cloth before collapsing for storage. Upper sections may be separated at Lever. Do not attempt to separate lower sections. Do not use lubricants. **Never collapse and store poles when wet or damp. This may lead to corrosion and will void warranty.**

Accumulation of dust & dirt in the locking buttons can lead to reduced locking function. While under warranty, we can service & clean your poles for free to fix this. Call us for details.

Rubber Tip Covers

Twist and pull tip covers to remove them. When attaching them, the pole tip should fit snugly inside the cover.